

T-REX AIRWALKERS® INSTRUCTION SHEET

ATTACHING WEIGHTS IS REQUIRED TO KEEP BALLOON FROM FLOATING AWAY


CAN BE
FILLED WITH
AIR OR
HELIUM

TRANSPORTATION


FOR EASE OF TRAVEL, INFLATE THE BALLOONS (HEAD AND TAIL WILL BE UNATTACHED), THEN COMPLETE ASSEMBLY AFTER TRANSPORTING THE BALLOON TO YOUR DESTINATION.

STEP 1 INFLATE BALLOONS IN THE FOLLOWING ORDER:


- A. ARMS
- B. LEGS
- C. BODY
- D. HEAD
- E. TAIL



STEP 2 USING INCLUDED, PRE-ATTACHED ADHESIVE CONNECTORS, ATTACH THE FOLLOWING, WHICH ARE LETTERED & NUMBERED CORRESPONDINGLY ON THE BALLOON.



ATTACH TAB (LETTER E) FROM HEAD TO ON BODY. ATTACH TABS (1) & (2) FROM BODY TO KNOCKOUTS ON HEAD. ATTACH TABS (6) & (7) ON HEAD TO KNOCKOUTS ON BODY.



ATTACH TAB (LETTER F) FROM BODY TO KNOCKOUT ON TAIL. ATTACH TABS (5) & (4) FROM TAIL TO KNOCKOUTS ON BODY. ATTACH TAB (3) ON BODY TO KNOCKOUT ON TAIL.

STEP 3 ATTACH WEIGHTS TO FEET AS INDICATED ABOVE. IF FILLING WITH AIR, ATTACH ADDITIONAL WEIGHT TO THE TAIL. IF FILLING WITH HELIUM, ATTACH ADDITIONAL WEIGHT TO THE HEAD.



FM36337